

RADIAL SERIES



RADIAL 34



RADIAL 26

Welcome to Osprey. We pride ourselves on creating the most functional, durable and innovative carrying product for your adventures. Please refer to this owner's manual for information on product features, use, maintenance, customer service and warranty.

OWNER'S MANUAL



ospreypacks.com

OVERVIEW



FEATURES

- 1 Separate top zip access to padded laptop and tablet sleeves
- 2 Main compartment with document sleeve and mesh pockets
- 3 Built-in, high visibility raincover
- 4 Front panel organization pocket
- 5 LidLock™ helmet attachment
- 6 Dual access front panel zippered shoe pocket (34L only)
- 7 Front panel stretch shove-it pocket sized for U-locks
- 8 Stretch side panel water bottle pocket
- 9 Blinker light attachment
- 10 Reflective detail on front panel
- 11 Zippered heat-embossed top pocket
- 12 Zippered heat-embossed side panel pocket with retractable keychain
- 13 Integrated kickstand keeps pack upright and accessible
- 14 Lower side compression straps

FABRIC

- MAIN** 420D x 400D Nylon Dobby
- ACCENT** 420D Nylon Packcloth
- BOTTOM** 200D x 400D Nylon Dobby

OVERVIEW

RADIAL 34

SPECS	S/M	M/L
Cubic Inches	1953	2075
Liters	32	34
Pounds	3.20	3.32
Kilograms	1.45	1.51
Inches	21h x 13w x 13d	
Centimeters	54h x 33w x 34d	



UNIQUE FEATURE

- 1 Dual-access front panel zippered shoe pocket

RADIAL 26

SPECS	S/M	M/L
Cubic Inches	1465	1587
Liters	24	26
Pounds	2.87	3.02
Kilograms	1.30	1.37
Inches	21h x 13w x 12d	
Centimeters	54h x 33w x 30d	





CARRY

1 MODIFIED AIRSPEED™ BACKPANEL

- + Suspended mesh backpanel for superior ventilation and comfort

2 VENTILATED SHOULDER HARNESS

- + Innovative ventilated stretch yoke and load lifters
- + Ventilating mesh-covered die-cut foam
- + Air mesh shoulder strap for comfort and ventilation
- + Adjustable sternum strap with safety whistle

3 WEBBING HIPBELT

- + Elastic hipbelt wing to maintain comfort while riding
- + Removable 25 mm webbing pack stabilizing hipbelt

SIZING / FIT



RADIAL - UNISEX SIZING

S/M 15-19" / 38-48 cm

M/L 18-22" / 46-56 cm



HARNESS FIT

The harness straps should wrap fully around your shoulders with no gaps between the pack and your back. The padded part of the harness straps should end 1"/2.5 cm - 2"/5 cm below the armpits and the sternum strap adjusted to approximately 2"/5 cm below the collarbone.

FEATURE DETAILS



INTEGRATED KICKSTAND

34L / 26L

An integrated kickstand keeps your pack upright whether loaded or empty and provides easy access to gear.



BLINKER LIGHT ATTACHMENT

34L / 26L

The blinker light attachment strap found near the base of the front panel of the pack allows for quick light attachment for high visibility in the dark.

- A Secure blinker light clip through reflective blinker light attachment loop.
- B Blinker light attachment loop is reflective, providing some visibility even without a blinker light.




LIDLOCK™ HELMET ATTACHMENT

34L / 26L

Osprey's LidLock™ easily and securely carries bicycle helmets.

- A Locate the LidLock™ helmet attachment clip near the top of the pack's front panel and pull away from the pack.
- B In the vertical position, pass LidLock™ through the helmet vent from the bottom and engage in the horizontal position.
- C Reverse process to detach helmet.



INTEGRATED REMOVABLE RAINCOVER

34L / 26L

- A Locate the raincover icon near the base of the pack.
- B Unzip the raincover compartment.
- C Pull the raincover from compartment and slip over the top and bottom of the pack.
- D Tension into place using the cord lock at the bottom of the raincover.
- E Reverse this process to return raincover to compartment.
- F To remove the raincover altogether, unfasten the hook and loop strap from the cord loop inside the raincover compartment.

Tip: To prevent mildew, remove raincover and allow to dry entirely after use in the rain.

FEATURE DETAILS



LOWER SIDE COMPRESSION STRAPS 34L / 26L

Lower side compression straps stabilize loads and narrow the pack's profile when packing light. To compress the pack, cinch the side straps, and lift the slider buckle to loosen.



FRONT PANEL ORGANIZATION POCKET 34L / 26L

The front panel pocket secures and stores pens, books and other small items.



ZIPPERED HEAT-EMBOSSSED TOP POCKET 34L / 26L

The zippered heat-embossed top pocket provides a secure and scratch-free storage solution for sunglasses and other fragile items.



ZIPPERED HEAT-EMBOSSSED SIDE PANEL WITH RETRACTABLE KEYCHAIN 34L / 26L

Keep your keys, phone and other small items secure, scratch-free and easy to access while on the go. The retractable keychain prevents accidentally dropping keys.



STRETCH SIDE PANEL WATER BOTTLE POCKET 34L / 26L

The stretch side panel water bottle pocket holds smaller bottles and is intentionally angled to provide access to the pocket's contents without removing the pack.



LAPTOP AND TABLET SLEEVE 34L / 26L LAPTOP SLEEVE

Inches	17.7h x 10.2w x 3.90d
Centimeters	49h x 26w x 10d

34L / 26L TABLET SLEEVE

Inches	12.2h x 9.1w x 2d
Centimeters	31h x 23w x 5d

For more information on this product and others, pack care, how to pack your pack, our lifetime guarantee, or to contact Osprey Customer Service, visit **ospreypacks.com**.

OWNER'S MANUAL



ospreypacks.com